

# **Saturn<sup>®</sup>**

**ST-HT8663**

**CONVECTION HEATER**



GB


## CONVECTION HEATER

Dear Buyer!  
We congratulate you on having bought the device under trade name "Saturn". We are sure that our devices will become faithful and reliable assistance in your housekeeping.

Avoid extreme temperature changes. Rapid temperature change (e.g. when the unit is moved from freezing temperature to a warm room) may cause condensation inside the unit and a malfunction when it is switched on. In this case leave the unit at room temperature for at least 1.5 hours before switching it on. If the unit has been in transit, leave it indoors for at least 1.5 hours before starting operation.

Please read the manual carefully prior to use.

### Product structure



### Note:

1. The product can not be placed directly below a fixed socket, because the product coverage or incorrect placement can cause a fire. It can not be used with the program, timers, or any other device. If the power cord is damaged, we must use our local dealer or service center to provide a dedicated power line to be replaced. Power cord and plug must be able to withstand more than 10A of load, and be a reliable ground!
2. When in use must not be placed in the bed or flammable, explosive and

other gases environment! Best on the floor or hung on the wall, between the heater and combustibles for at least 80 cm above the distance! !

3. In the course of an abnormality is found, shall be promptly disconnect the power, do not disassemble, and notify the company in the local dealer or our service department for maintenance.
4. In the course do not frequent the control switch on or off when not in use, disconnect the power cord unplugged!
5. In use, is strictly prohibited in the outlet or any object covered with sticks and other foreign matter into the protective cover to prevent accidents!
6. During use, the elderly, children or persons with mobility problems should be under the guidance of his family's care or use.
7. Service life - 4 years.

### Installation:

1. Open the packaging, remove the product, verify that the product in good condition.
2. Use a screwdriver to remove the link back of the product, installed in the following table according to size of the hooks on the wall.

### Usage:

1. Before the use of the convection heater make sure that the data of the device corresponds the data of your mains.
2. Plug the power cord into the socket.
3. Make the thermostat on the control panel to maximum.
4. You can set the power knob for heating at the modes I or II.
- 5 This convection heater is equipped with the 2 hours timer.
6. If the heating reached your desired temperature, turn temperature control knob counterclockwise until you hear the sound, and the convection heater will stop working.
7. In the course of the convection heater will automatically maintain the temperature you set. When the room temperature reaches the temperature you set, the convection heater will automatically stop working. When the indoor temperature is lower than the temperature you set, the convection heater will automatically open the work in cycles, in order to maintain the best indoor temperature.





- 1.
- 2.
- 3.
4. 2
5. 2
- 6.
- 7.

1.

10 A,

2.

80

3.

4.

5.

6.

1.

2.

3.

1.

2.

7. - 4

1.

2.

2000  
220-240  
50  
9 A

1

1

1



# Saturn®

## INTERNATIONAL MANUFACTURER'S WARRANTY

## MEZINÁRODNÍ ZÁRUKA

GB

### INTERNATIONAL MANUFACTURER'S WARRANTY

The Warranty is provided for the period of 2 years or more if the Law on User Right of the country where the appliance was bought provides for a greater minimum warranty period.

All terms of warranty comply with to the Law on Protection of the Consumer Rights and are governed by the legislation of the country where the product was bought. The warranty and free of charge repair are provided in any country where the product is delivered to by Saturn Home Appliances or authorized representative thereof, and where no restriction of import or other legal provisions interfere with rendering of warranty services and free of charge repair.

Cases uncovered by the warranty and free of charge repair:

1. Guarantee coupon is filled in improperly.
2. The product has become inoperable because of the Buyer's nonobservance of the service regulations indicated in the instruction.
3. The product was used for professional, commercial or industrial purposes (except for the models, specially intended for this purpose that is indicated in the instruction).
4. The product has external mechanical damage or damage caused by penetration of the liquid inside, dust, insects and other foreign objects.
5. The product has damages caused by non-observance of the rules of power supply from batteries, mains or accumulators.
6. The product was exposed to opening, repair or modification of design by the persons, unauthorized to repair; independent cleaning of internal mechanisms etc. was made.
7. The product has natural wear of parts with limited service life, expendables etc.
8. The product has deposits of scale inside or outside of fire-bar elements, irrespective of used water quality.
9. The product has damages caused by effect of high (low) temperatures or fire on non-heat resistant parts of the product.
10. The product has damages of accessories and nozzles which are included into the complete set of product shipment (filters, grids, bags, flasks, cups, covers, knives, sealing rings, graters, disks, plates, tubes, hoses, brushes, and also power cords, headphone cords etc.).
11. A defect was a result of inappropriate installing of the appliance by non-specialists of the supplier's authorized service center.

On the warranty service and repair, please contact the authorized service centers of "Saturn Home Appliances".

MEZI NÁRODNÍ ZÁRUKA

Záruka se poskytuje na dobu 2 roky.V p ípad že Zákon na ochranu spot ebitele dané zem na izuje delší dobu, prodlužuje se záruka na tuto dobu.

Veškeré záru ní podmínky odpovídají Zákonu o ochran práv uživatel a jsou ízené zákonodárstvím státu, kde byl výrobek koupen. Záruka a bezplatná oprava se poskytují v každém stát ,kam jsou výrobky dodané společností „Saturn Home Appliances“ nebo jejím zplnomocn ým zástupcem a kde nejsou žádná omezení na dovoz nebo jiné právní p edpisy omezující poskytnutí záru ního servisu a bezplatné opravy.

- P ípady,na které se záruka a bezplatná oprava nevztahují
1. Záru ní list je vypln n nesprávn .
  2. Výrobek byl poškozen kv li tomu, že zákazník nesplnil pravidla použití, která jsou uvedena v návodu.
  3. Výrobek byl používán k profesionálním, komer ním nebo pr myslovým cíl m (krom model speciáln ur ených pro tyto cíle, což je uvedeno v návodu).
  4. Výrobek má vn jší mechanická poškození nebo poškození, vyvolaná tím, že se dovnit dostala tekutina, prach, hmyz a jiné cizí p edm ty.
  5. Výrobek má poškození, která jsou vyvolaná nespln ním pravidel napájení od baterií, síť nebo akumulátor .
  6. Výrobek rozebírali, opravovali nebo m nili jeho konstrukci lidé, kte í nebyli zplnomocn ni k oprav , bylo provedeno samostatné íšt ní vnit ních mechanism a pod.
  7. Výrobek má p írozené opot ebov ání díl s omezenou dobou použití, spot ebních materiál atd.
  8. Výrobek má vrstvu usazeniny uvnit nebo zvenku termoelektrických oh íva , bez ohledu na kvalitu používané vody.
  9. Výrobek má poškození, která jsou vyvolaná p sobením vysokých (nizkých) teplot nebo ohn na termonestabilní ásti výrobku.
  10. Výrobek má poškozené p ísluženství a nástavce, které jsou dodané spolu s výrobkem (filtry, sí ky, sá ky, ba ky, mísy, víka, nože, šleha e, struhadla, kotou e, talí e, trubky, hadice, kartá e a také sí ové š ry, sluchátkové š ry atd.).
  11. Vada je d sledkem nesprávné instalace výrobku neoprávn nou osobou.

V otázkách záru ního servisu a oprav se obračejte na autorizovaná servisní st ediska společnosti „Saturn Home Appliances“.

1. . . . .
2. . . . .
3. . . . .
4. ( ).
5. . . . .
6. . . . .
7. . . . .
8. . . . .
9. . . . . ( )
10. ( . . . . . )
11. . . . .

«Saturn Home Appliances»

« Saturn Home Appliances» .

: <http://saturn.ua/ru/servis>,  
: 0-800 505-27-09



, 84		8(86132) 3-66-02						
, 55	« »	8(86132)5-05-00	+	+		+	+	
, 81, 3	« »	8(343) 361-11-77 8(343) 361-11-78	+		+	+	+	
, 64	« »	8(343) 240-26-60	+		+			
, 7, 201	«GOLD»	8(919) 372-28-04			+			+
, 31, 2	« - »	8(343) 385-12-89	+	+	+	+	+	
, 47	« »	8(47467) 4-12-08 8(47467) 4-33-17	+		+			
, 22		8(86359) 4-32-23 8(86359) 4-06-42			+			
, 45/6	« - »	8(4932) 335185 8(4932) 335236	+	+	+	+	+	
» 7 ( « - » )	« 26»	8(86545) 2-74-74			+			
, 4	« - »	8(3412) 30-79-79 8(3412) 30-83-07	+		+	+	+	
, 76	« - »	8(3412) 78-76-85 8(3412) 78-06-64	+		+	+	+	
, 7/1, 301, 307	« - »	8(3412) 44-60-40 8(3412) 44-60-67			+			
, 24	« »	8(8362) 24-11-24 8(8362) 25-55-40	+	+	+	+	+	
, 24	« »	8(3952) 42-55-76 8(3952) 78-15-83	+		+	+	+	
, 56	« »	8(3952) 28-74-50 8(3952) 76-71-75			+		+	+
, 183	« - »	8(34551) 7-46-31						+
, 9	«VIP-SERVIS»	8(843) 258-92-15	+		+	+	+	
100, 45	« »	8(843) 240-64-94	+	+	+	+	+	
, 163	«1000»	8(4012) 58-83-54 8(4012) 76-04-77	+		+			
, 33	-	8(3439) 39-95-20 8(34399) 34-74-40	+	+	+	+	+	
, 6	« »	8(84457) 9-17-43 8(84457) 9-45-89	+	+	+	+	+	
, 157		8(8734) 44-42-44	+	+		+	+	
, 53/2	-	8(3842) 35-39-67	+			+		

, 17	« »	8(87239) 2-33-55 8(87239) 3-01-77	+	+	+	+	+	
, 42	« - »	8(8332) 56-25-95 8(8332) 54-70-77	+		+	+	+	
, 96	« »	8(86393) 2-10-43			+			
, 9	-	8(988) 548-24-36	+		+			
, 2,		8(86142) 4-43-59	+	+	+	+	+	
, 1	« »	8(918) 936-36-53			+		+	+
, 3	« - »	8(861) 267-50-88	+	+	+	+	+	
, 103,	« - - »	8(861) 222-64-13 8(861) 222-85-55 8(905) 408-08-38	+	+	+	+	+	
.55		8(861) 235-49-68	+	+	+	+	+	
, 16		8(918) 102-00-10 8(961) 501-92-22	+	+	+	+	+	
, 1\1	« - »	8(86156) 3-40-40 8(918) 990-35-04	+		+	+	+	
, 106	« »	8(86164) 7-01-22			+			
, 116		8(86145) 3-78-74			+			+
, 57	« »	8(86164) 65-4-95 8(918) 355-81-70	+	+		+	+	
, 25	« »	8(86153) 4-16-70			+			
, 1		8(86 151) 4-10-92	+	+	+	+	+	
, 242, 1		8(3912) 92-92-22 8(3912) 41-78-88	+	+	+	+	+	
, 6	« »	8(3912) 93-54-33 8(3912) 94-52-82	+	+	+	+	+	
, 1	« »	8(4712) 50-85-90 8(4712) 35-04-91	+	+	+	+	+	
, 36-	« +»	8(4712) 51-45-75	+	+	+	+	+	
37-	« »							
, 5								



17	«	8(4712) 54-74-24	+	+	+	+	+
2	«	8(86169) 7-39-99 8(86169) 7-24-96	+	+	+	+	+
66	«	8(4742) 33-45-65 8(4742) 33-45-95	+	+	+	+	+
25	«	8(8772) 55-62-38		+			+
164	«	8( 8722) 93-30-73	+	+	+	+	+
14-21	«-ise»	8(8722) 63-23-94 8(8722) 93-55-15	+	+	+	+	+
11	«	8(86385) 2-33-26 8(960) 458-07-11	+	+		+	+
9	«X»	8(909) 401-35-21	+	+	+	+	+
3 ( )	«	8(495) 721-30-70 8(499) 168-05-19 8(499) 168-47-15	+		+	+	+
20 (30/05)	«	8(8552) 359002 8(8522) 359042	+	+	+	+	+
154 (52/28)	«VIP-SERVIS»	8(8552) 99-91-45	+	+	+	+	+
24	«-»	8(8662) 42-04-30 8(8662) 42-12-21	+		+	+	
55	«	8(86554) 5-59-77 8(86554) 3-67-57	+	+	+	+	+
10	«-»	8(34783) 3-43-44	+	+	+	+	+
9 ( « »)	«	8(8555) 48-08-80 8(917) 906-60-06	+		+	+	+
51	«-»	8 (831) 220-84-94 8 (831) 413-82-91	+		+		
18	«-»	8(831) 46-18-848		+			+
6		8(831) 46-18-848		+			+
18	«	8(3843) 20-31-33	+		+	+	+
21/27	«	8(48762) 6-46-46	+	+	+	+	+
14	«-»	8(8617) 63-11-15 8(8617) 63-03-95	+		+	+	
17	«-»	8(383)274-99-33 8(383) 274-99-45	+		+		

63, 3	«	8(383) 210-59-49 8(383) 210-52-92	+		+	+	
2	«	8(383) 351-39-19	+		+		
24	«	8(86369) 3-74-75 8(928) 609-35-85	+	+	+		
4		8(3532) 36-87-94	+			+	+
5-1	«-»	8(3812) 577-092 8(3812) 576-329	+		+		
194	«-»	8(3812) 36-74-01					+
130	«	8(3812) 36-42-02	+	+	+	+	
25	«-+»	8(3537) 37-23-83	+	+	+	+	+
11	«-»	8(3537) 35-79-93 8(3537) 20-60-70	+	+	+	+	+
11-	«-»	8(3537) 35-79-93 8(987) 796-00-19	+	+	+	+	+
3,	«-»	8(342) 221-40-99	+	+	+	+	+
19, 1	«-»	8(342) 240-88-88 8(342) 205-57-88	+	+	+	+	+
11	«	8(342) 240-93-35 8(342) 240-93-24		+			
11	«-»	8(8142) 78-06-93 8(8142) 70-65-48	+		+		
39-5		8(3846) 69-33-00	+	+	+	+	+
11	«	8 (8112)-53-86-30 8 (8112)-53-86-50	+		+		+
5-13		8(8793) 98-70-11 8-918-743-69-46	+	+	+	+	+
50-		8(47396) 48-911	+	+	+	+	+
18		8(47396) 47-676	+	+	+	+	+
37	«-»	8(863) 250-47-77	+		+		
7	«-»	8(863) 227-60-90 8(863) 299-00-50	+	+	+	+	+
50-1/52,	«	8(863) 21-92-112 8(800) 100-51-52	+	+	+	+	+
55		8(906) 453-35-81	+		+		
11-		8(906) 453-35-81	+		+		
17-	«	8(86370) 2-19-50	+	+	+	+	+

14								
12	« »	8(4855) 22-04-77 8(4855) 25-38-60	+	+	+	+	+	
21	« »	8(4855) 24-31-21	+	+	+	+	+	
14, 1	« - »	8(4912) 76-88-01 8(4912) 40-30-30	+	+	+	+	+	
42-	« - »	8(4912) 41-33-02	+	+	+	+	+	
100/ 56	« - »	8(846) 990-37-51 8(846) 240-98-17	+	+	+	+	+	
149	« - - »	(846) 979-9-979	+	+	+	+	+	
e 197	« XXI »	8(812) 600-11-97	+	+	+	+		
e 41-	« - »	8(812) 325-36-56 8(812) 325-36-57	+		+	+		
e 11, 36-	« -95 »	8(812) 822-18-00 8(812) 320-06-61	+					
1	« - »	8(8342) 23-05-91 8(8342) 47-48-59	+	+	+			
95	« - »	8(8452) 52-81-21 8(8452) 52-83-84	+	+	+	+	+	
253-	« »	8(496) 547-04-95 8(496) 549-32-79	+	+		+	+	
47	« -S »	8(963) 624-49-46			+	+	+	
44	« »	8(4812) 45-05-13 8(920) 333-09-44	+	+	+	+	+	
90	« »	8(8622) 55-51-19 8(8622) 55-01-08	+			+	+	
63	« »	8(8652) 24-30-14 8(8652) 23-31-81	+	+	+	+	+	
15- 21	« »	8(8652) 95-53-68 8(8652) 95-61-90		+				
3/4	« »	8(8652) 44-88-66		+				
1	« - »	8(4725) 24-62-27 8(4725) 24-73-49	+	+	+			
158	« - »	8(3473) 20-12-13 8(3473) 20-27-70	+		+	+	+	
25	« »	8(8212) 22-95-29 8(8212) 29-12-20	+	+	+	+	+	

137-	« -2000 »	8(4752) 56-19-42 8(4752) 56-19-44	+	+	+	+	+	
18	« »	8(4822) 47-65-65 8(4822) 47-58-58	+	+	+	+	+	
24/2		8(86130) 4-86-59 8(918)147-02-03	+	+		+	+	
2/2	« - »	8(86196) 7-20-53	+	+	+	+	+	
48	« + »	8(8482) 22-72-41 8(8482) 22-71-85 8(8482) 61-65-64	+	+	+	+	+	
115	« »	8(910) 949-68-44 8(953) 182-61-82	+	+	+	+	+	
169/5	« »	8(3452) 75-95-08 8(3452) 20-82-65	+		+	+		
24	« »	8(9292) 69-56-60; 60-56-60-	+	+	+	+	+	
55	« »	8(3452) 47-35-69	+		+	+	+	
28	« »	8(3012) 21-89-63	+		+	+	+	
16/7	« »	8(8422) 73-44-22 8(8422) 73-29-19	+	+		+	+	
6/1	« - »	8(347) 236-57-07	+		+			
59	« - »	(347) 2281701	+		+	+	+	
7; 153; 42	« »	8(347) 279-90-70 8(347) 241-62-02						+
70-	« -lse »	8(928) 048-93-10	+	+	+	+	+	
15-	« »	8(86391) 2-18-06	+		+			
36	« »	8(8352) 62-30-97 8(4942) 63-20-98	+		+			
8		8(351) 239-39-34 8(351) 239-39-35	+	+	+	+	+	
57 3	« »	8(351) 225-13-13 8(351) 236-12-40	+		+	+	+	
340-	« - »	8(8782) 27-30-60 8(8782) 27-70-77	+	+	+	+	+	
48, 11	« . »	8(8782) 25-04-66 8(8782) 25-19-15	+	+	+	+	+	
13	« - »	8(8782) 23-91-26 8(928) 385-22-42	+	+	+	+	+	
33	« »	8(3022) 36-39-36 8(3022) 36-39-32	+	+	+	+	+	

1		8(904) 345-83-18	+	+	+	+	+
3-21-	« »	8(84722) 9-52-07 8(937) 469-52-07	+	+	+	+	+
57	« - »	8(8453) 55-80-89 8(964) 848-45-06	+		+	+	+
12	« - »	8(4852) 25-94-83	+		+		

UA

«Saturn Home Appliances»

- 1.
- 2.
- 3.
- 4.
- 5.
- 6.
- 7.
- 8.
- 9.
- 10.
- 11.

« Saturn Home Appliances» .

: <http://saturn.ua>,  
0-800 502-502



, 242		(0623) 22-55-50 (066) 103-22-88 (097) 776-81-20	+	+	+	-	-	-	-
, 1		(0623) 41-37-58	+	+	+	+	+	+	+
. 50- 32\18		(0629) 49-60-05 (0629) 49-30-06	+	+	+	+	+	-	+
, 227	( « ) »	(0629) 47-30-00 (098) 312-26-28 (095) 028-26-28	+	+	+	+	+	-	+
, 84		(0629) 49-18-81 (067) 597-56-15	+	+	+	+	+	-	+
, 51-		(04337) 6-48-47 (0432) 46-82-13	+	+	+	+	+	+	+
, 46		(03131) 3-73-37 (03131) 3-73-36 (099) 797-44-30 (097) 342-35-51	+	+	+	-	+	+	-
, 33	« »	(0512) 47-04-96 (0512) 47-83-48	+	+	+	+	+	+	+
, 2		(0512) 58-06-47	+	+	+	+	+	+	-
, 49	« »	(0512) 58-21-80 (067) 517-05-70 (066) 705-64-44	-	+	+	+	+	+	-
, 97, 2	« - » ( )	(05662) 4-15-03 (099) 074-35-53	+	+	+	+	+	+	+
, 38		(095) 724-72-66	+	+	+	+	+	+	-
, 38	« »	(04141) 5-20-10	+	+	+	+	+	-	+
, 90		(048) 700-17-3 (048) 787-45-79	+	+	+	+	+	+	+
, 55		(0482) 39-06-18 (094) 839-06-19	+	+	+	+	+	-	+
, 2 ( , 66)		(048) 731-77-03 (048) 731-77-04	+	+	+	-	-	-	+
, 172-		(05632) 6-15-54 (05632) 6-23-42	+	+	+	+	+	-	+
, 75		(096) 284-08-36 (066) 085-75-39	+	+	+	+	+	+	+
, 29		(0532) 69-42-62 (099) 60-14-24	+	+	+	+	+	+	+
, 120		(0532) 50-98-89 (050) 013-72-17	+	+	+	+	+	-	+
, 66		(0532) 61-56-21	+	+	+	+	+	+	+

, 101/1		(04637) 3-85-95 (095) 886-21-99 (063) 597-41-27 (067) 272-57-51	-	+	+	+	+	+	+
, 12		(0362) 26-65-85	+	+	+	+	+	-	+
, 5		(0362) 43-33-40 (067) 360-42-42	+	+	+	+	+	+	+
, 1		(06434) 2-60-25 (099) 271-01-47	+	+	+	+	+	+	+
, 24		(06452) 5-05-33 (050) 603-72-72	+	+	+	+	+	+	+
, 32		(04733)-46182	+	+	+	+	+	+	+
, 1		(06444) 4-02-89 (066) 105-39-66	+	+	+	+	+	-	+
, 171- \10		(03245)-58381	+	+	+	-	-	-	-
, 19		(096) 340-06-96	+	+	+	+	+	+	+
, 86/1		(0542) 660-300, 650-340, 655-510							
, 2	« »	(067) 357-63-78 (050) 512-48-87	+	+	+	+	+	+	+
, 1/24	« - »	(04744) 4-66-14 (04744) 4-61-34	+	+	+	-	-	-	-
, 3/2		(0312) 65-42-66 (099) 557-53-07	+	+	+	+	+	+	+
, 3	« »	(057) 734-97-24 (057) 712-51-81	+	+	+	+	-	+	-
, 12		(057) 717-13-39 (057) 702-16-20	+	+	+	+	+	+	+
( , 18, , 42 )	« »	(096) 595-37-46	+	+	+	-	-	+	+
, 35		(0552) 42-02-35	-	-	-	+	-	-	-
, 28-		(0552) 43-40-40 (050) 494-60-43	+	+	+	+	+	+	+
, 23		(0552) 29-60-42	+	+	+	+	+	+	+
, 7		(0382) 66-45-01 (063) 075-08-89	+	+	+	-	-	+	+
, 2		(0382) 70-47-00 (0382) 70-47-07 (03822) 66-46-16	+	+	+	+	+	-	-
, 18		(0382) 78-37-73 (0382) 78-37-55	+	+	+	+	+	+	+
	« -	(0472) 56-34-78	+	+	+	+	+	+	+

. , 146, 102	»	(0472) 50-03-54 (0472) 56-42-16 (096) 505-63-63								
. , 71	« »	(0472) 31-46-57 (0472) 56-56-21	+	+	+	-	-	-	+	
. 77- , 1	« »	(0462)-601585	+	+	+	+	+	-	-	
. , 105		(0372) 55-48-69 (050) 434-55-29	+	+	+	-	+	+	+	
. , 3		(03840) 4-00-17 (067) 360-16-32	+	+	+	+	+	+	+	

GB

## WARRANTY COUPON

When purchasing the product,  
please require its checking before you;

BE SURE

that the goods sold to you, are functional and complete  
and that the warranty coupon is filled in correctly.

This warranty coupon confirms the absence of any defects in the product you purchased and provides for free of charge repair of the product failed through the fault of the manufacturer throughout the period of warranty service and free of charge repair.

Failing the presentation of this coupon, in case of its improper filling in, infringement of factory seals (if any), and also in cases indicated in the warranty obligations, the claims are not accepted, and no warranty service and free of charge repair is made!

The warranty coupon is valid only in the original copy with the stamp of trading organization, signature of the seller, date of sale and signature of the buyer.

Complex home appliances should be installed by supplier's authorized service centers, authorized specialists. In the case of a malfunction of the home appliance because of incorrect installation, the buyer must pay the cost of the visit (call) of the specialist, as well as the cost of fault diagnostics if necessary.

CZ

## ZÁRUČNÍ LIST

Při koupi výrobku  
žádejte o jeho vyzkoušení ve Vaší přítomnosti,

PĚŠVĎTESE

že Vám prodaný výrobek je dobře fungující a kompletní  
a že záruční list je vyplněn správně.

Tento záruční list potvrzuje, že na Vámi koupeném výrobku nejsou žádné vady a zajišťuje bezplatnou opravu nefungujícího přístroje z viny výrobce, během celé záruční doby.

Bez předložení tohoto listu, při jeho nesprávném vyplnění, porušení plomb výrobce (jsou-li na výrobku) a také v případech, které jsou uvedené v záručním listě, nároky se nepřijímají a záruční oprava se neprovádí!

Záruční list je platný jenom jako originál s razítkem obchodní organizace, podpisem prodávajícího, termínem prodeje a podpisem zákazníka.

Instalace komplexní spotřebiče musí být provedena autorizovaným servisním střediskem, specialistou. V případě poruchy v důsledku nesprávné instalace výrobku, kupující je povinen uhradit náklady na výjezd (volání) odborný, pokud je to nezbytné, a náklady na diagnostiku poruch.

RU

# Saturn®

WARRANTY COUPON

ZÁRUČNÍ LIST

SATURN HOME APPLIANCES S.R.O. KONVOVA 141, 13083  
PRAHA 3 – ŽIŽKOV, ČESKÁ REPUBLIKA, TEL: + 4202/ 67 108 392

Model/

Serial number/Sériové číslo/

Date of sell/Termín prodeje/

Shop stamp/Razítko obchodu/

Seller's signature/Podpis prodávající/

Buyer's Signature confirming the acquaintance and consent with terms of free of charge maintenance service of the product, and absence of the complaints on appearance and color of the product. Podpis zákazníka, potvrzující seznámení a souhlas s podmínkami bezplatného záručního servisu výrobku, a také neexistence nároků na vzhled a barvu výrobku.

UA







